

PPW Powe Perris, California 92571

> Phone: (951) 436-7900 Tech: (888) 377-9779

HARMONIC BALANCER **BOLT INSTALLATION**

PART NUMBER: 1042265

COMPONENTS QTY BOITS

- 1. Make sure there is an adequate chamfer around the bolt holes on the flexplate to clear the radius under the head of the bolt.
- Install washer (if supplied) and hand tighten the bolt.
- Torque the bolts to 90 ft.lbs.

GET MORE INFO. VISIT US ONLINE

NEED HELP? GIVE US A CALL!